



INSTALLATION INSTRUCTION

WL220207



Important Instructions. Please read first.

- Please follow instructions carefully. Failure to do so will void the warranty. Please ensure installation complies with local law and applicable standards.
- 1. Ensure correct input voltage is supplied to the luminaire.
- 2. Ensure the power is disconnected before making any connections.
- 3. Do not make modification nor alter the luminaire without written approval from GLP.
- 4. Ensure to keep luminaire in a clean area free of debris.




INSTALLATION

- **Step 1:** Find a location where the luminaire has to be installed. Install suitable wiring from the mains supply (180-250VAC, 50/60Hz) to the luminaire.
- **Step 2:** Unscrew and take out the front cover and diffuser of the luminaire.





- **Step 3:** Drill holes on the wall and fix provided fischers.





All the Installation and Maintenance must be done by Technicians and Professional Engineers





- **Step 4:** Fix the luminaire electrical compartment on the wall using screws and connect it to the main cable.



- **Step 5:** Fix the diffuser on the luminaire electrical compartment using screws.



- **Step 6:** Put the front cover back on the diffuser.



Make sure the main power is
switched off during installation.

All the Installation and Maintenance must be done by Technicians and Professional Engineers