

## INSTALLATION INSTRUCTIONS

FL440209


### Important Instructions. Please read first.

- Please follow instructions carefully. Failure to do so will void warranty. Please ensure installation complies with local law and applicable standards.
  1. Only use a GLP power supply unit.
  2. Ensure correct input voltage is connected to the luminaire.
  3. Ensure the power is disconnected before making any connections.
  4. Do not make modification or alter the luminaire without written approval of GLP.
  5. Ensure to keep luminaire in a clean area free of debris.




## INSTALLATION

**Step 1:** Loosen and remove screws using a screwdriver. Separate the main light body from the circular mounting plate base.




**Step 2:** Secure the base plate to the surface using appropriate screws, feeding the power cable through the center of the base.






**GLOBAL LIGHT  
& POWER LLC**  
AN LED LIGHTING COMPANY


**Step 3:** Prepare the wires to the required length and connect the power source wires to the corresponding terminals.



**Step 4:** If RGBW light, connect all wires to their respective terminals.



**Step 5:** Place the light body onto the secured base, re-insert and tighten screw to firmly secure the light body to the mounting base.



**Step 6:** Turn the power ON as shown in diagram. Adjust the light's direction by rotating it up to 350° horizontally and tilting it up to 70° vertically.



Make sure the main power is switched off during installation.

**All the Installation and Maintenance must be done by Technicians and Professional Engineers**