



INSTALLATION INSTRUCTION


WL220541

Important Instructions. Please read first.



- Please follow instructions carefully. Failure to do so will void the warranty. Please ensure installation complies with local law and applicable standards.
 1. Ensure correct input voltage is supplied to the luminaire.
 2. Ensure the power is disconnected before making any connections.
 3. Do not make modification nor alter the luminaire without written approval from GLP.
 4. Ensure to keep luminaire in a clean area free of debris.

INSTALLATION

- **Step 1:** Find a location where the luminaire has to be installed. Install suitable wiring from the main supply (180V-250V AC, 50/60Hz) to the luminaire.
- **Step 2:** Unscrew and remove mounting clamp from the luminaire.




- **Step 3:** Drill holes on the wall and fix provided fishers.




All the Installation and Maintenance must be done by Technicians and Professional Engineers





- **Step 4:** Fix the mounting clamp on the wall using screws.



- **Step 5:** Connect the main cable to the luminaire using terminal blocks or connector. Wrap the connection using electrical tape.



- **Step 6:** Fix the luminaire on the mounting clamp using screws.



Make sure the main power is
switched off during installations.

All the Installation and Maintenance must be done by Technicians and Professional Engineers